

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5400011    PWS NAME: CELINA CITY

PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001

STU ID: 5456396    STU NAME: CELINA CITY

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>BROMATE</b>	BROMATE - 1011	1 Sample(s) Monthly
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2008 and 10/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 4/1/2008 and 4/30/2008 1 Sample(s) between 5/1/2008 and 5/31/2008 1 Sample(s) between 6/1/2008 and 6/30/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>BROMATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5400011      PWS NAME: CELINA CITY

PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: CELINA CITY DISTRIBUTION

Effective Date: 7/18/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
REVISED - LEAD - 1030 & COPPER - 1022	60 Sample(s) between 7/1/2008 and 12/31/2008
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 4 Sample(s) Quarterly
TOTAL COLIFORM (TCR) - 3100	10 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
Lead & Copper Initial Monitoring Sample Date(s):	1st Half Sample Date(s)						2nd Half Sample Date(s)					
	Jan - Mar Sample Date(s)			Apr - Jun Sample Date(s)			Jul - Sept Sample Date(s)			Oct - Dec Sample Date(s)		
HAA5 & TTHM Quarterly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
TCR Monthly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5400112 PWS NAME: COLDWATER VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456397 STU NAME: COLDWATER VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5400112      PWS NAME: COLDWATER VILLAGE PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: COLDWATER, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	5 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
HAA5 & TTHM Sample Date(s):												
TCR Monthly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5400212 PWS NAME: FORT RECOVERY VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456398 STU NAME: FORT RECOVERY VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5400312 PWS NAME: GRAND LAKE MHP**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456399 STU NAME: GRAND LAKE MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5400412    PWS NAME: LAKE SHORE RESORT  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456400    STU NAME: LAKE SHORE RESORT  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5400612 PWS NAME: MENDON VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456401 STU NAME: MENDON WTP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5400912    PWS NAME: NORTHMOOR LANDINGS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456404    STU NAME: NORTHMOOR LANDINGS  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5401012    PWS NAME: PARK GRAND RESORT  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456405    STU NAME: PARK GRAND RESORT  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5401112 PWS NAME: ROCKFORD VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456406 STU NAME: ROCKFORD VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH5401212    PWS NAME: ST CHARLES SEMINARY**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 5456407    STU NAME: SAINT CHARLES SEMINARY**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 7/1/2008 and 9/30/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5401312 PWS NAME: SAINT HENRY VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456408 STU NAME: SAINT HENRY WTP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5401412    PWS NAME: THE LAURELS OF SHANE HILL**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5456409    STU NAME: LAURELS OF SHANE HILL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5401412      PWS NAME: THE LAURELS OF SHANE HILL

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: THE LAURELS OF SHANE HILL DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5401512    PWS NAME: SPIRITUAL CENTER OF MARIA STEIN**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456410    STU NAME: SPIRITUAL CENTER OF MARIA STEIN**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5401612    PWS NAME: WOODHAVEN MHP PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456411    STU NAME: WOODHAVEN MHP  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5401712    PWS NAME: COTTONWOOD PARK  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456412    STU NAME: COTTONWOOD PARK INC  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5402012      PWS NAME: CLUB ISLAND ASSOCIATION**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5456415    STU NAME: CLUB ISLAND ASSOCIATION STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5402112      PWS NAME: BAYVIEW WATER ASSOCIATION**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 5456416      STU NAME: BAYVIEW WATER ASSOCIATION**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)





**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5430012    PWS NAME: AMERICAN LEGION POST 345**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456419    STU NAME: AMERICAN LEGION POST 345**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5430112    PWS NAME: AMERICAN LEGION POST 571**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456420    STU NAME: AMERICAN LEGION POST 571**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5430612    PWS NAME: BEHMS LANDING A  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456422    STU NAME: BEHMS LANDING A  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5430912    PWS NAME: NEILS RESTAURANT & BAR

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5456423    STU NAME: NEILS RESTAURANT & BAR


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5431112    PWS NAME: CARTER LUMBER CO CELINA**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456424    STU NAME: CARTER LUMBER CO CELINA STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5431412    PWS NAME: CHATT HOME RESTAURANT**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456427    STU NAME: CHATT HOME RESTAURANT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5431712    PWS NAME: EDEN HAVEN PARK-EAST**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456428    STU NAME: EDEN HAVEN PARK EAST**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5431812    PWS NAME: EDEN HAVEN PARK-WEST**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456429    STU NAME: EDEN HAVEN PARK WEST**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5432012    PWS NAME: MERCER CO ELKS CLUB 2170**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456430    STU NAME: ELKS CLUB NO 2170 SOUTH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 3/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5432212    PWS NAME: SUNNY SIDE INN  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456432    STU NAME: SUNNY SIDE INN  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5432412 PWS NAME: FRANKLIN ELEMENTARY SCHOOL-CELINA**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456433 STU NAME: FRANKLIN ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5432412 PWS NAME: FRANKLIN ELEMENTARY SCHOOL-CELINA**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: FRANKLIN ELEMENTARY SCH. DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

**Use for Sample Tracking Purposes**

---

<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
--------------------------------------	---------------------------------	---------------------------------	----------------------------------	---------------------------------

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5432512 PWS NAME: FORT RECOVERY INDUSTRIES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5456434 STU NAME: FORT RECOVERY INDUSTRIES INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5432512      PWS NAME: FORT RECOVERY INDUSTRIES

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: FORT RECOVERY INDUSTRIES DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5432812      PWS NAME: SHINGLE SHACK RESTAURANT**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 5456435      STU NAME: SHINGLE SHACK REST STU 1**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5433112    PWS NAME: KNIGHTS OF SAINT JOHN PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456436    STU NAME: KNIGHTS OF ST. JOHN**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5433212    PWS NAME: LAKE DRIVE IN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456437    STU NAME: LAKE DRIVE IN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5433412      PWS NAME: MARION LOCAL ELEMENTARY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456438      STU NAME: MARION LOCAL ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5433412      PWS NAME: MARION LOCAL ELEMENTARY

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: MARION LOCAL ELEMENTARY DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

Use for Sample Tracking Purposes	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5433512      PWS NAME: MARION LOCAL HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456439      STU NAME: MARION LOCAL HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5433512 PWS NAME: MARION LOCAL HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: MARION LOCAL HIGH SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5433712    PWS NAME: BUNGE PARK**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456441    STU NAME: BUNGE PARK**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5433812    PWS NAME: MOTOR INN AUTO TRUCK STOP PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456442    STU NAME: MOTOR INN AUTO TRUCK STOP STU 1**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5434112    PWS NAME: NORTHMOOR GOLF LLC  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456443    STU NAME: NORTHMOOR COUNTRY CLUB  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5434512    PWS NAME: CHRISTIAN CHURCH INC  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456444    STU NAME: CHRISTIAN CHURCH INC.  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5434712    PWS NAME: PIT STOP TAVERN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456445    STU NAME: PIT STOP TAVERN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5434812    PWS NAME: PHILOTHEA COUNTRY CLUB**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456446    STU NAME: PHILOTHEA COUNTRY CLUB INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5435412    PWS NAME: ST. JOE STORE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456448    STU NAME: SAINT JOE STORE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5435612    PWS NAME: ST. PAULS UNITED CHURCH OF CHRIST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456450    STU NAME: SAINT PAULS U CHURCH OF CHRIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5435912    PWS NAME: STARLIGHT DRIVE IN THEATER**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456451    STU NAME: STARLIGHT DRIVE IN THEATER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5436412 PWS NAME: ZION LUTHERAN CHURCH - ROCKFORD**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5456452 STU NAME: ZION LUTHERAN CHURCH - ROCKFORD**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5436812    PWS NAME: RANCH TAVERN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456453    STU NAME: RANCH TAVERN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5437212    PWS NAME: DOSS LANDING  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456456    STU NAME: DOSS LANDING  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5437312    PWS NAME: DUCKFOOT-ARNOLD LANDING**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456457    STU NAME: DUCKFOOT-ARNOLD LANDING**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5437412    PWS NAME: HECHTS LANDING - WELL #1**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456458    STU NAME: HECHTS LNDNG BTHHS WELL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5437512    PWS NAME: HECHTS LANDING 2 WELL PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456459    STU NAME: HECHTS LANDING LGTPL WELL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5437812      PWS NAME: HEMMELGARN & SONS, INC. PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456460      STU NAME: HEMMELGARN AND SONS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5437812      PWS NAME: HEMMELGARN & SONS, INC. PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: HEMMELGARN AND SONS, INC DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5438012 PWS NAME: KORNER KAFE - MARIA STEIN**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5456461 STU NAME: KORNER KAFE - MARIA STEIN**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5438212      PWS NAME: PAX MACHINE WORKS, INC.**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456462      STU NAME: PAX MACHINE WORKS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5438212      PWS NAME: PAX MACHINE WORKS, INC.

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: PAX MACHINE WORKS, INC. DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

Use for Sample Tracking Purposes	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5438412    PWS NAME: TSC STORE 240 PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456463    STU NAME: TSC STORE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5438512    PWS NAME: VFW POST 5135  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456464    STU NAME: VFW POST 5135  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5438612    PWS NAME: WAGON WHEEL NITE CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456465    STU NAME: WAGON WHEEL NITE CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5438712    PWS NAME: WENDELIN TAVERN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456466    STU NAME: WENDELIN TAVERN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5438912    PWS NAME: BAYVIEW SUN & SNOW**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456467    STU NAME: BAYVIEW LODGE INC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5439012    PWS NAME: WINDY CORNERS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456468    STU NAME: WINDY CORNERS  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5439212    PWS NAME: ITS IT LANDING PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456469    STU NAME: ITS IT LANDING**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5439312    PWS NAME: LEES LANDING PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456470    STU NAME: LEES LANDING**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5439412    PWS NAME: LEFELD IMPLEMENT, INC.**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456471    STU NAME: LEFELD IMPLEMENT INC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5439612    PWS NAME: SCHWIETERMAN FAMILY PHYSICIANS INC.**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5456472    STU NAME: SCHWIETERMAN FAMILY PHYSICIANS INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5439712    PWS NAME: D & W MARINA**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456473    STU NAME: D & W MARINA**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5439812    PWS NAME: KOZY KAMP GROUND - BATH HOUSE WELL

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5456474    STU NAME: KOZY KAMP GROUND - BATH HOUSE WELL


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5439912      PWS NAME: MONTEZUMA BAY RESORT

PWS TYPE: Transient Noncommunity      SOURCE: Ground Water

STU ID: 5456475      STU NAME: MONTEZUMA BAY RESORT


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5440112      PWS NAME: ODOT-MERCER CO GARAGE PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456477      STU NAME: ODOT MERCER CO GARAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2008 and 10/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5440112 PWS NAME: ODOT-MERCER CO GARAGE PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ODOT-MERCER CO GARAGE DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

**Use for Sample Tracking Purposes**

---

	<i>1st Half Sample Date(s)</i>	<i>2nd Half Sample Date(s)</i>		
<i>Lead &amp; Copper Initial Monitoring Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5440312      PWS NAME: S AND K PRODUCTS COMPANY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5456479      STU NAME: S & K PRODUCTS CO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5440312 PWS NAME: S AND K PRODUCTS COMPANY**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: S&K PRODUCTS COMPANY DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5440412    PWS NAME: BEHMS LANDING RESTAURANT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5456480    STU NAME: BEHMS LANDING RESTAURANT STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5440412    PWS NAME: BEHMS LANDING RESTAURANT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5460520    STU NAME: BEHMS LANDING RESTAURANT STU 2**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP002</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5440512    PWS NAME: ODNR-GRAND LAKE ST. MARYS STATE PARK-WIN

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5460724    STU NAME: ODNR WINDY POINT


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5440612    PWS NAME: MARIA STEIN CENTER  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5456481    STU NAME: MARIA STEIN CENTER  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5440812    PWS NAME: KOZY KAMP GROUND**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5460688    STU NAME: KOZY KAMP GROUND**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5440912    PWS NAME: DEERFIELD GOLF COURSE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5460675    STU NAME: DEERFIELD GOLF COURSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5441012    PWS NAME: BEHMS LANDING B  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5460723    STU NAME: BEHMS LANDING B  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5441112    PWS NAME: NIEKAMP FARM & FLEA MARKET

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5460739    STU NAME: NIEKAMP FARM & FLEA MARKET


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5441212    PWS NAME: BUCKS INN PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5460819    STU NAME: BUCKS INN  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5441312    PWS NAME: VFW POST 6515 PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5460851    STU NAME: VFW POST 6515**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5441412    PWS NAME: HECHTS LANDING MHP  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5461007    STU NAME: HECHTS LANDING MHP  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5441512    PWS NAME: ZUMA THRU/SUNSET LAUNDRY/CAR WASH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5461589    STU NAME: ZUMA THRU/SUNSET LAUNDRY/CAR WASH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5441612    PWS NAME: MAPLEWOOD OF SHANES VILLAGE PWS**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5461839    STU NAME: MAPLEWOOD OF SHANES VILLAGE**

**Effective Date: 5/16/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2008 and 10/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5441612 PWS NAME: MAPLEWOOD OF SHANES VILLAGE PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: MAPLEWOOD OF SHANES VILLAGE DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---