

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6700003      PWS NAME: AURORA CITY PWS

PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: AURORA, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	<b>**</b> 4 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	15 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	<b>***</b> Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6700212 PWS NAME: BEECHWOOD ISLAND ESTATES**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757276 STU NAME: BEECHWOOD ISLAND ESTATES ASSN**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6700312    PWS NAME: BIRCHWOOD MANOR MHC-OLD.PARK

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757277    STU NAME: BIRCHWOOD MANOR OLD PARK

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6700322    PWS NAME: BIRCHWOOD MANOR MHC-NEW PARK

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757278    STU NAME: BIRCHWOOD MANOR NEW PARK

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6700412 PWS NAME: BLACKBROOK VALLEY ESTATE**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757279 STU NAME: BLACKBROOK VALLEY ESTATES**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6700512 PWS NAME: OHIO AMERICAN WATER-AURORA E**

**PWS TYPE: Community SOURCE: Purchased Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: OH AMERICAN WATER-AURORA DIST**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	<b>**</b> 1 Sample(s) Quarterly
<b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>	4 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	<b>***</b> Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
	<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6700612      PWS NAME: MODERN MANAGEMENT - PM ESTATES PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 6757281    STU NAME: MODERN MANAGEMENT SOLUTIONS DBA PM ESTAT**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6700812    PWS NAME: MODERN MANAGEMENT - ALL SEASONS MHP  
PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001  
STU ID: 6757282    STU NAME: MODERN MANAGEMENT SOLUTIONS DBA ALL SEAS  
Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6700912      PWS NAME: COUNTRY ESTATES MHP**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757283    STU NAME: COUNTRY ESTATES MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6700912      PWS NAME: COUNTRY ESTATES MHP

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: COUNTRY ESTATES MHP DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6701312    PWS NAME: FAIRLANE WATER CO.

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757286    STU NAME: FAIRLANE WATER CO

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
NITRATE Sample Date(s):
SOC Group 1 Sample Date(s):
Date CCR sent to Ohio EPA:



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6701412      PWS NAME: GARRETTSVILLE VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757287    STU NAME: GARRETTSVILLE WATER DEPARTMENT

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
NITRATE Sample Date(s):
SOC Group 1 Sample Date(s):
Date CCR sent to Ohio EPA:



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6701612 PWS NAME: HIRAM VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757288 STU NAME: HIRAM WTP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6701812 PWS NAME: KENT CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757289 STU NAME: KENT WTP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6701812      PWS NAME: KENT CITY PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: KENT, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	30 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	50 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>												
	<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6701912 PWS NAME: KENT TRAILER PARK

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP002

STU ID: 6760577 STU NAME: KENT TRAILER PARK STU 2

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
ARSENIC Quarterly Sample Date(s):				
NITRATE Sample Date(s):				
VOC Quarterly Sample Date(s):				
SOC Group 1 Sample Date(s):				
Date CCR sent to Ohio EPA:				



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6702112      PWS NAME: M & M MOBILE HOME PARK

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001

STU ID: 6757291      STU NAME: M & M MHP

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6702112      PWS NAME: M & M MOBILE HOME PARK

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: M & M MOBILE HOME PARK DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6702212 PWS NAME: MANTUA VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757292 STU NAME: MANTUA VILLAGE OF**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6702312 PWS NAME: MAPLE DEL MANOR LLC**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757293 STU NAME: MAPLE DEL MANOR MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6702412      PWS NAME: NELSON LEDGES ESTATES MHP

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757294    STU NAME: NELSON LEDGES ESTATE MHP

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
NITRATE Sample Date(s):
SOC Group 1 Sample Date(s):
Date CCR sent to Ohio EPA:



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6702512 PWS NAME: ORCHARD ESTATES MOBILE PARK**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757295 STU NAME: ORCHARD ESTATES MOBILE PARK**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6702612      PWS NAME: PINE GATE VILLAGE**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757296    STU NAME: PINE GATE MOBILE VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6702612      PWS NAME: PINE GATE VILLAGE

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: PINE GATE MOBILE VILLAGE DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6702812 PWS NAME: PORTAGE CO-SHALERSVILLE**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757298 STU NAME: PORTAGE CO-SHALERSVILLE STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6702812    PWS NAME: PORTAGE CO-SHALERSVILLE

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: PORTAGE CO-SHALERSVILLE DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 2 Sample(s) Quarterly
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
HAA5 & TTHM Quarterly Sample Date(s):	Jan - Mar Sample Date(s)			Apr - Jun Sample Date(s)			Jul - Sept Sample Date(s)			Oct - Dec Sample Date(s)		
TCR Monthly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6703012    PWS NAME: RANCH CLUB ESTATES WATER ASSOCIATION  
PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001  
STU ID: 6757300    STU NAME: RANCH CLUB EST WATER ASSN  
Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH6703112    PWS NAME: FOX RUN ESTATES PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 6757301    STU NAME: FOX RUN ESTATES**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6703112      PWS NAME: FOX RUN ESTATES PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: FOX RUN ESTATES DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6703211 PWS NAME: RAVENNA CITY PWS**

**PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: EP001**

**STU ID: 6757302 STU NAME: RAVENNA WTP**

**Effective Date: 2/19/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>REVISED - CHLORITE</b>	CHLORITE - 1009	1 Sample daily when Chlorine Dioxide is applied
<b>REVISED - CHLORINE DIOXIDE</b>	CHLORINE DIOXIDE RESIDUAL - 1008	1 Sample daily when Chlorine Dioxide is applied
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>CHLORITE Sample Date(s):</i>												
<i>CHLORINE DIOXIDE Sample Date(s)</i>												
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6703312 PWS NAME: ROBIN PARK MOBILE HOMES**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757303 STU NAME: ROBIN MHPS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6703312      PWS NAME: ROBIN PARK MOBILE HOMES

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: ROBIN PARK MOBILE HOMES DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6703503 PWS NAME: ROOTSTOWN WATER COMPANY PWS**

**PWS TYPE: Community SOURCE: Purchased Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: ROOTSTOWN WATER SERVICE DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	20 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	7 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6703612      PWS NAME: SANDLEWOOD WATER COMPANY

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757305    STU NAME: SANDLEWOOD WATER CO

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6703612 PWS NAME: SANDLEWOOD WATER COMPANY**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: SANDLEWOOD WATER COMPANY DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>																							
<i>Lead &amp; Copper Sample Date(s):</i>																							
<table border="0" style="width:100%; text-align:center;"> <tr> <td><i>Jan</i></td> <td><i>Feb</i></td> <td><i>Mar</i></td> <td><i>Apr</i></td> <td><i>May</i></td> <td><i>Jun</i></td> <td><i>Jul</i></td> <td><i>Aug</i></td> <td><i>Sept</i></td> <td><i>Oct</i></td> <td><i>Nov</i></td> <td><i>Dec</i></td> </tr> </table>												<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>												
<i>TCR Monthly Sample Date(s):</i>																							
<i>Total Chlorine Sample Date(s):</i>																							

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6703812    PWS NAME: NORTH BENTON SHORES ASSOCIATION  
PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001  
STU ID: 6757307    STU NAME: NORTH BENTON SHORES ASSOC INC  
Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6703912      PWS NAME: SPRING LAKES MOBILE HOME PARK**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757308      STU NAME: SPRING LAKES LTD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**  
**PWS ID: OH6703912 PWS NAME: SPRING LAKES MOBILE HOME PARK**  
**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000**  
**FACILITY NAME: SPRING LAKES MOBILE HOME DISTRIBUTION**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6704012    PWS NAME: STONERIDGE TOWNHOUSES**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757309    STU NAME: STONERIDGE APARTMENTS**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6704012      PWS NAME: STONERIDGE TOWNHOUSES

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: STONERIDGE TOWNHOUSES DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6704212    PWS NAME: PINE MANOR MOBILE HOME PARK

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757311    STU NAME: PINE MANOR MHP

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6704212      PWS NAME: PINE MANOR MOBILE HOME PARK**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: PINE MANOR MOBILE HOME P DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH6704712 PWS NAME: COUNTRYSIDE ESTATES**  
**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**  
**STU ID: 6757315 STU NAME: COUNTRYSIDE ESTATES**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH6704812 PWS NAME: WINDHAM VILLAGE PWS**  
**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**  
**STU ID: 6757316 STU NAME: WINDHAM WTP**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6704812      PWS NAME: WINDHAM VILLAGE PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: WINDHAM,VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	3 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6705112 PWS NAME: HOMESTEAD MANOR MHP**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757320 STU NAME: HOMESTEAD MANOR MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6705112      PWS NAME: HOMESTEAD MANOR MHP

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: HOMESTEAD MANOR MOBILE H DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6705212      PWS NAME: OHIO AMERICAN WATER-BEECHCREST**

**PWS TYPE: Community      SOURCE: Purchased Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: OH AMER WATER-BEECHCREST DIST**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	2 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6705312 PWS NAME: PORTAGE CO-RIVERMOOR**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757322 STU NAME: PORTAGE CO.-RIVERMOOR**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6705512      PWS NAME: MEADOW CREEK CONDO ASSOC**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757324      STU NAME: MEADOW CREEK CONDO ASSOC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6705712    PWS NAME: WEST PARK ESTATES LLC

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757326    STU NAME: WEST PARK ESTATES LLC

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH6705912    PWS NAME: JUST CRICKET CONDO ASSOCIATION

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 6757328    STU NAME: JUST CRICKET CONDO ASSOCIATION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6706012 PWS NAME: PORTAGE CO-BRIMFIELD**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757329 STU NAME: BRIMFIELD WTP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6730812      PWS NAME: COUNTY LINE BAR & GRILL

PWS TYPE: Transient Noncommunity      SOURCE: Ground Water

STU ID: 6757334      STU NAME: COUNTY LINE BAR & GRILL


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6731712    PWS NAME: BOBS PIZZA PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757337    STU NAME: BOBS PIZZA**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6733312    PWS NAME: CAMP CARL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757340    STU NAME: CAMP CARL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6733512    PWS NAME: CAMP JESSIE MAE FAGEOL**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757341    STU NAME: CAMP JESSIE MAE FAGEOL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6734412      PWS NAME: CENTRAL ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757344      STU NAME: CENTRAL ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6734412 PWS NAME: CENTRAL ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: CENTRAL ELEMENTARY SCH DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6734812    PWS NAME: CERTIFIED OIL CO-STATION 410 PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757345    STU NAME: CERTIFIED GAS STATION 410**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6735012 PWS NAME: CHEROKEE PARK COMPANY**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757346 STU NAME: CHEROKEE PARK CO**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6735112    PWS NAME: CHURCH OF JESUS CHRIST OF LDS-ROOTSTOWN**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757347    STU NAME: CHURCH OF JESUS CHRIST LD SAINT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6735412    PWS NAME: CLUBHOUSE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757348    STU NAME: CLUBHOUSE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6738112    PWS NAME: DR. ROACH OUTDOOR LEAGUE CAMPGROUND PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757351    STU NAME: DR ROACHS OUTDOOR CAMP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6738612    PWS NAME: DUTCH HARBOR MARINA**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757353    STU NAME: DUTCH HARBOR MARINA**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6738712 PWS NAME: EAST MANUFACTURING CORP**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757354 STU NAME: EAST MANUFACTURING CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6738712 PWS NAME: EAST MANUFACTURING CORP**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: EAST MANUFACTURING CORP DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6738912    PWS NAME: DAIRY QUEEN-EDINBURG**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757355    STU NAME: DAIRY QUEEN EDINBURG**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6740112 PWS NAME: FIELD HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757356 STU NAME: FIELD HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6740112 PWS NAME: FIELD HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: FIELD HIGH SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6740212 PWS NAME: FIELD MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757357 STU NAME: FIELD JR HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6740212      PWS NAME: FIELD MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: FIELD JR HIGH SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6740312      PWS NAME: FIRST BAPTIST CHURCH OF ATWATER**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757358      STU NAME: FIRST BAPTIST CHURCH ATWATER**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6740312 PWS NAME: FIRST BAPTIST CHURCH OF ATWATER**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: FIRST BAPTIST CHURCH ATWATER DISTRIBUTIO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6740612    PWS NAME: FRIENDSHIP ACRES CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757359    STU NAME: FRIENDSHIP ACRES CAMP STU 1**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6740612    PWS NAME: FRIENDSHIP ACRES CAMPGROUND

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6760580    STU NAME: FRIENDSHIP ACRES CAMP STU 2


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP002</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6741212    PWS NAME: GERMAN FAMILY SOCIETY**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757360    STU NAME: GERMAN FAMILY SOCIETY**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6741512    PWS NAME: GREEN HILLS GOLF COURSE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757361    STU NAME: GREEN HILLS GOLF**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6742412    PWS NAME: HIDDEN COVE RESORT  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757362    STU NAME: HIDDEN COVE RESORT  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

**PWS ID: OH6742512    PWS NAME: HIDDEN VALLEY CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757363    STU NAME: HIDDEN VALLEY CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6742912    PWS NAME: HILLSIDE GARDENS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757364    STU NAME: HILLSIDE GARDENS**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6745112    PWS NAME: KENT STATE GOLF-CLUBHOUSE

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757369    STU NAME: KENT STATE GOLF CLUBHOUSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6745212    PWS NAME: KIMES CORNERS CAMPGROUND

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757370    STU NAME: KIMES CORNERS


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6745512    PWS NAME: KOOL LAKES FAMILY CAMPGROUND-CLUBHOUSE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757371    STU NAME: KOOL LAKES FAMILY CAMPGROUND - CLUBHOUSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6745612    PWS NAME: KOOL LAKES FAMILY CAMPGROUND-SHOWER**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757372    STU NAME: KOOL LAKES FAMILY CAMPGROUND - SHOWER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6745712    PWS NAME: PIONEER TRAIL CAMPGROUND (LDS) PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6761630    STU NAME: PIONEER TRAIL CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6745812    PWS NAME: BRADCO SUPPLY CORP PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6761891    STU NAME: BRADCO SUPPLY CORP**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6746612    PWS NAME: LEISURE LAKE PARK  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757376    STU NAME: LEISURE LAKE PARK  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6747012    PWS NAME: MAPLECREST GOLF COMPANY**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757377    STU NAME: MAPLECREST GOLF CO**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6747112    PWS NAME: DUSTY ARMADILLO  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757378    STU NAME: DUSTY ARMADILLO  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH6748412    PWS NAME: MOGADORE VFW POST 8487

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757383    STU NAME: MOGADORE VFW POST 8487


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6748912    PWS NAME: NELSON LEDGES QUARRY PARK

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757384    STU NAME: NELSON LEDGES QUARRY PK


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6749012      PWS NAME: OAK GROVE GOLF COURSE

PWS TYPE: Transient Noncommunity      SOURCE: Ground Water

STU ID: 6757385      STU NAME: OAK GROVE GOLF COURSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6749412    PWS NAME: COUNTRYSIDE CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757386    STU NAME: COUNTRYSIDE CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6749612 PWS NAME: PARADISE LAKE COUNTRY CLUB**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757387 STU NAME: PARADISE LAKE COUNTRY CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6749812    PWS NAME: PARIS INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757388    STU NAME: PARIS INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6750512    PWS NAME: PORTAGE FAITH UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757389    STU NAME: PORTAGE FAITH UNITED METHODIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6750712    PWS NAME: SETTLERS INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757390    STU NAME: SETTLERS INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6751112    PWS NAME: RANDOLPH FAIR PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6760806    STU NAME: RANDOLPH FAIR STU 1  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6751112    PWS NAME: RANDOLPH FAIR PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6760807    STU NAME: RANDOLPH FAIR STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP002</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6751112    PWS NAME: RANDOLPH FAIR PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6760808    STU NAME: RANDOLPH FAIR STU 3  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP003</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP003 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6751212    PWS NAME: ROSES RANDOLPH INN  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757391    STU NAME: ROSES RANDOLPH INN  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6751712    PWS NAME: RAVENSWOOD GOLF CLUB

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757394    STU NAME: RAVENSWOOD GOLF CLUB


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6752312    PWS NAME: ROUND UP, LLC  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757398    STU NAME: ROUNDUP LLC  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6752912    PWS NAME: SCHULTZ LAKE INC.**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757399    STU NAME: SCHULTZ LAKE INC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6753012    PWS NAME: SEBRING COUNTRY CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757400    STU NAME: SEBRING COUNTRY CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6753512 PWS NAME: SOUTHEAST HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757401 STU NAME: SOUTHEAST HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH6753512      PWS NAME: SOUTHEAST HIGH SCHOOL

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: SOUTHEAST HIGH SCHOOL DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6753612    PWS NAME: SOUTHEAST ELEMENTARY SCHOOL PWS**  
**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 6757402    STU NAME: SOUTHEAST ELEMENTARY SCHOOL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6753612      PWS NAME: SOUTHEAST ELEMENTARY SCHOOL PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: SOUTHEAST ELEMENTARY SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6753912      PWS NAME: ST. JOSEPH SCHOOL-MOGADORE**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757403      STU NAME: SAINT JOSEPH SCHOOL - MOGADORE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6753912 PWS NAME: ST. JOSEPH SCHOOL-MOGADORE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ST. JOSEPH SCHOOL-MOGADO DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

---

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6754012      PWS NAME: ST. JOSEPH SCHOOL-MANTUA**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757404      STU NAME: SAINT JOSEPH SCHOOL MANTUA**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6754012 PWS NAME: ST. JOSEPH SCHOOL-MANTUA**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ST. JOSEPH SCHOOL-MANTUA DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6754312      PWS NAME: SUFFIELD ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757405      STU NAME: SUFFIELD ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6754312 PWS NAME: SUFFIELD ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: SUFFIELD ELEMENTARY SCH DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6754612    PWS NAME: SUNNY HILLS GOLF & RECREATION**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757407    STU NAME: SUNNY HILL GOLF & REC INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6755212    PWS NAME: THE OUTPOST**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757409    STU NAME: THE OUTPOST**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6755812    PWS NAME: TUCKAWAY LAKE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757411    STU NAME: TUCKAWAY LAKE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6756112    PWS NAME: AMF TWIN STAR LANES**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757412    STU NAME: AMF TWIN STAR LANES**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6756912      PWS NAME: WATERLOO K-12 CAMPUS PWS**  
**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**  
**STU ID: 6757414      STU NAME: WATERLOO K-12 CAMPUS**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>



**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6757112    PWS NAME: WHISPERING PINES CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757415    STU NAME: WHISPERING PINES**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6758112      PWS NAME: WOODSIDE LAKE PARK-FRONT**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 6757417      STU NAME: WOODSIDE LAKE PARK-FRONT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6758212    PWS NAME: WOODSIDE LAKE PARK-REAR**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757418    STU NAME: WOODSIDE LAKE PARK-REAR**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6759912    PWS NAME: VAUGHNS MARKET 43 PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6761886    STU NAME: VAUGHNS MARKET 43


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6762012    PWS NAME: RANDOLPH TOWN HALL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757420    STU NAME: RANDOLPH TOWN HALL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6762612    PWS NAME: RUSTY NAIL RESTAURANT

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757421    STU NAME: RUSTY NAIL RESTAURANT


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6762912    PWS NAME: SAVE 4 STORE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757422    STU NAME: SAVE 4 STORE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6763012    PWS NAME: RANDOLPH SUNOCO**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757423    STU NAME: RANDOLPH SUNOCO**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6763112    PWS NAME: SCOTT MOLDERS INCORPORATED**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757424    STU NAME: SCOTT MOLDERS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 4/1/2008 and 6/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6763112 PWS NAME: SCOTT MOLDERS INCORPORATED**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: SCOTT MOLDERS INCORPORAT DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6763312 PWS NAME: RACCOON HILL GOLF CLUB**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757425 STU NAME: RACCOON HILL GOLF CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6763812    PWS NAME: BIG T DINER PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6762183    STU NAME: BIG T DINER**  
**Effective Date: 5/16/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
REVISED - NITRITE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6764212    PWS NAME: SUFFIELD FELLOWSHIP CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757426    STU NAME: SUFFIELD FELLOWSHIP CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6765112    PWS NAME: TAVERN AT TWIN LAKES, INC.**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757428    STU NAME: TAVERN AT TWIN LAKES INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6765412    PWS NAME: STREETSBORO UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757429    STU NAME: STREETSBORO UNITED METHODIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6765612    PWS NAME: ARNIES WEST BRANCH STEAK**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757430    STU NAME: ARNIES WEST BRANCH STEAK HOUSE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6765812    PWS NAME: WISE CHEVROLET INC  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757431    STU NAME: WISE CHEVROLET INC  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6766412 PWS NAME: ODNR-WEST BRANCH-EAST BOAT RAMP**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757433 STU NAME: ODNR WEST BRANCH ST PK E BOAT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6766711    PWS NAME: ODNR-WEST BRANCH-TOWER**  
**PWS TYPE: Transient Noncommunity    SOURCE: Surface Water**  
**STU ID: 6757435    STU NAME: ODNR WEST BRANCH TOWER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) Monthly between 0/0/2008 and 0/0/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	4 Sample(s) Monthly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes												
Nitrate Monthly Sample Date(s):	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
Nitrite Sample Date(s):												
TCR Monthly Sample Date(s):	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6767112 PWS NAME: ODNR-NELSON LEDGES STATE PARK**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757436 STU NAME: ODNR NELSON LEDGES**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6767512    PWS NAME: ODOT REST AREA 4-36  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757438    STU NAME: ODOT REST AREA 4-36  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6767612 PWS NAME: ODOT REST AREA 4-35 PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757439 STU NAME: ODOT REST AREA 4-35**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6768412    PWS NAME: THE CHURCH  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757440    STU NAME: THE CHURCH  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6768612    PWS NAME: CIRCLE RESTAURANT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757441    STU NAME: CIRCLE RESTAURANT INC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH6770112    PWS NAME: JOHNSON FARM**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757445    STU NAME: JOHNSON FARM LDS CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6770212    PWS NAME: KNIGHTS OF COLUMBUS 2039 PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757446    STU NAME: KNIGHTS OF COLUMBUS NO 2039**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6772212    PWS NAME: TWIN LAKES COUNTRY CLUB**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757450    STU NAME: TWIN LAKES COUNTRY CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6773412 PWS NAME: HAPPY DAY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757453 STU NAME: HAPPY DAY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6773412 PWS NAME: HAPPY DAY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: HAPPY DAY SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6774212    PWS NAME: STREETSBORO KOA**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757458    STU NAME: STREETSBORO KOA**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6774312 PWS NAME: PALMYRA UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757459 STU NAME: PALMYRA UNITED METHODIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6774412    PWS NAME: CAMP ASBURY-CENTRAL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757460    STU NAME: CAMP ASBURY CENTRAL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6774512    PWS NAME: MID-WAY DRIVE-IN THEATER**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757461    STU NAME: MID-WAY DRIVE-IN THEATRE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6774812    PWS NAME: OLD COUNTRY INN  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757462    STU NAME: OLD COUNTRY INN  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6775012    PWS NAME: TOWNERS WOODS PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757464    STU NAME: TOWNERS WOODS  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6775112    PWS NAME: VICTORY BAPTIST TEMPLE

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757465    STU NAME: VICTORY BAPTIST TEMPLE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6775512    PWS NAME: LAKEVIEW CHAPEL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757468    STU NAME: LAKEVIEW CHAPEL  
Effective Date: 2/19/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
REVISED - TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6776312    PWS NAME: SUFFIELD UNITED CHURCH OF CHRIST

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6757470    STU NAME: SUFFIELD UNITED CHURCH CHRIST


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6776412    PWS NAME: SUFFIELD SPRINGS GOLF**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757471    STU NAME: SUFFIELD SPRINGS GOLF CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6776712      PWS NAME: OUR COUNTRY PRESCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757472      STU NAME: OUR COUNTRY PRESCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6776712 PWS NAME: OUR COUNTRY PRESCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: OUR COUNTRY PRESCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6776812      PWS NAME: H&M RUBBER COMPANY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757473      STU NAME: H & M RUBBER CO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 4/1/2008 and 6/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6776812 PWS NAME: H&M RUBBER COMPANY**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: H&M RUBBER COMPANY DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6777212    PWS NAME: EDINBURG UNIT CHURCH/SCHOOL**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757474    STU NAME: EDINBURG UNITED CHURCH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6777212 PWS NAME: EDINBURG UNIT CHURCH/SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: EDINBURG UNIT CHURCH/SCH DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6777512    PWS NAME: HARRISON MACHINE & PLASTIC CORP**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757477    STU NAME: HARRISON MACHINE & PLASTIC CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6777512 PWS NAME: HARRISON MACHINE & PLASTIC CORP**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: HARRISON MACHINE/PLASTIC DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6777612    PWS NAME: CIRCLE K 5371-ATWATER  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757478    STU NAME: CIRCLE K 5371-ATWATER  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6778012      PWS NAME: TRELLEBORG WHEEL SYSTEMS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757480      STU NAME: TRELLEBORG WHEEL SYSTEM AMERICAS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6778012      PWS NAME: TRELLEBORG WHEEL SYSTEMS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: TRELLEBORG WHEEL SYSTEMS DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6778112    PWS NAME: CHRISTYS CAMP PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757481    STU NAME: CHRISTYS CAMP  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6778312    PWS NAME: CIRCLE K 5363-RANDOLPH**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757482    STU NAME: CIRCLE K 5363-RANDOLPH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6778612    PWS NAME: CAMP ASBURY- SHAW**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757485    STU NAME: CAMP ASBURY-SHAW**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6778712 PWS NAME: TWIN LAKES ASSOC.- BEACH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757486 STU NAME: TWIN LAKES ASSOCIATION BEACH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 6/1/2008 and 8/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6779512    PWS NAME: PORTAGE PRIVATE INDUSTRY COUNCIL**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6757492    STU NAME: PORTAGE PRIVATE INDUSTRY COUNCIL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6779512 PWS NAME: PORTAGE PRIVATE INDUSTRY COUNCIL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: PORTAGE PRIVATE INDUSTRY COUNCIL DISTRIB**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6779712    PWS NAME: HI OAKS CAMPGROUND**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757494    STU NAME: HI OAKS CAMPGROUND**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6779812 PWS NAME: COUNTRY ACRES CAMPGROUND 1-BOAT HOUSE PW**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757495 STU NAME: COUNTRY ACRES CAMPGROUND 1**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6779912    PWS NAME: COUNTRY ACRES CAMPGROUND 2- SHOWER HOUSE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757496    STU NAME: COUNTRY ACRES CAMPGROUND 2**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6780012 PWS NAME: COUNTRY ACRES CAMPGROUND 3- POOL HOUSE P**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757497 STU NAME: COUNTRY ACRES CAMPGROUND 3**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6780112    PWS NAME: COUNTRY ACRES CAMPGROUND 4- SOUTH SIDE P**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757498    STU NAME: COUNTRY ACRES CAMPGROUND 4**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6780412    PWS NAME: FREEDOM INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757501    STU NAME: FREEDOM INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6780512      PWS NAME: PORTAGE METRO. HOUSING AUTHORITY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757502      STU NAME: PORTAGE METRO HOUSING AUTHORITY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 4/1/2008 and 6/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6780512    PWS NAME: PORTAGE METRO. HOUSING AUTHORITY**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: DS000**

**FACILITY NAME: PORTAGE METRO.HOUSING AU DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6780612    PWS NAME: EASTWOOD MOTEL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757503    STU NAME: EASTWOOD MOTEL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6780712 PWS NAME: ATWATER COMMUNITY CHURCH OF THE NAZARENE**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757504 STU NAME: ATWATER COMM. CHURCH/ NAZARENE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6780812    PWS NAME: KINSEY KORNER**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757505    STU NAME: KINSEY KORNER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6781012 PWS NAME: QUIKRETE COMPANIES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757506 STU NAME: QUIKRETE COMPANIES**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6781012 PWS NAME: QUIKRETE COMPANIES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: QUIKRETE COMPANIES DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6781112    PWS NAME: WINDMILL LAKES  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757507    STU NAME: WINDMILL LAKES CIPRIANOS  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6781912      PWS NAME: GOODYEAR - AIRSHIP OPS.**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6757514      STU NAME: GOODYEAR AIRSHIP OPS**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6781912 PWS NAME: GOODYEAR - AIRSHIP OPS.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: GOODYEAR - AIRSHIP OPS. DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6782112 PWS NAME: TIGER TECH DAY CARE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757516 STU NAME: TIGER TECH DAY CARE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6782112 PWS NAME: TIGER TECH DAY CARE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: TIGER TECH DAY CARE DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6782312 PWS NAME: CHURCH OF JESUS CHRIST OF LDS - HIRAM**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6757518 STU NAME: CHURCH OF JC LDS HIRAM**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6782512    PWS NAME: BRIMFIELD STEAKHOUSE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757519    STU NAME: BRIMFIELD STEAKHOUSE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6782712 PWS NAME: CANTEX, INC.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6757521 STU NAME: CANTEX INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6782712 PWS NAME: CANTEX, INC.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: CANTEX, INC. DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6782812    PWS NAME: KENTWOOD RESTAURANT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6757522    STU NAME: KENTWOOD RESTAURANT**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6782912    PWS NAME: CROSSROADS COMMUNITY CHURCH-RAVENNA**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6757523    STU NAME: CROSSROADS COMMUNITY CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6783012    PWS NAME: MANGIAMO PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6757524    STU NAME: MANGIAMO  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6783412 PWS NAME: CHURCH OF GOD-BRIMFIELD**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6760670 STU NAME: CHURCH OF GOD-BRIMFIELD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6783412      PWS NAME: CHURCH OF GOD-BRIMFIELD**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: CHURCH OF GOD - BRIMFIELD DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6783512    PWS NAME: TIME OUT SPORTS BAR**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6760752    STU NAME: TIME OUT SPORTS BAR GRILL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6783612    PWS NAME: ELKS CLUB 1377 PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6760753    STU NAME: ELKS CLUB NO 1377  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6783812    PWS NAME: THE DIAMOND LODGE PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6760766    STU NAME: THE DIAMOND LODGE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6783912    PWS NAME: ODNR-WEST BRANCH HORSE CAMP PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6760794    STU NAME: ODNR WEST BRANCH HORSE CAMP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6784012      PWS NAME: PLANET EARTH PRESCHOOL, INC PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 6760837      STU NAME: PLANET EARTH PRESCHOOL, INC.**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	CONTACT OHIO EPA
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6784012 PWS NAME: PLANET EARTH PRESCHOOL, INC PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: PLANET EARTH PRESCHOOL, INC DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH6784212    PWS NAME: JAGERS PUB PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 6760967    STU NAME: JAGERS PUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6784312 PWS NAME: KALE CREEK GOLF COURSE PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 6760978 STU NAME: KALE CREEK GOLF**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH6784712    PWS NAME: MULLIGAN SPRINGS GOLF COURSE PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6761273    STU NAME: MULLIGAN SPRINGS GOLF COURSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6784912    PWS NAME: SOUTHEAST MIDDLE SCHOOL PWS**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6761299    STU NAME: SOUTHEAST MIDDLE SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6784912 PWS NAME: SOUTHEAST MIDDLE SCHOOL PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: SOUTHEAST MIDDLE SCHOOL DISTRIBUTION**

**Effective Date: 2/19/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>REVISED - LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6785012    PWS NAME: MCDERMOTT'S LAKEFRONT CAMPGROUND PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6761373    STU NAME: MCDERMOTT'S LAKEFRONT CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6785212    PWS NAME: RANGE RESOURCES-APPALACHIA, LLC**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 6761572    STU NAME: RANGE RESOURCES-APPALACHIA, LLC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6785212 PWS NAME: RANGE RESOURCES-APPALACHIA, LLC**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: RANGE RESOURCES-APPALACHIA LLC DIST**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH6785312 PWS NAME: KIDS AHEAD-EAST PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 6761588 STU NAME: KIDS AHEAD-EAST**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH6785312 PWS NAME: KIDS AHEAD-EAST PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: KIDS AHEAD-EAST DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH6785412    PWS NAME: ST NICHOLAS ORTHODOX CHURCH PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 6761598    STU NAME: ST NICHOLAS ORTHODOX CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH6785512    PWS NAME: RANDOLPH TWP FIELD HOUSE PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6761637    STU NAME: RANDOLPH TWP FIELD HOUSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH6785612    PWS NAME: FAMILY DOLLAR DEERFIELD PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6761935    STU NAME: FAMILY DOLLAR DEERFIELD


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH6785912    PWS NAME: BOOYAH'S PIZZA  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 6762007    STU NAME: BOOYAH'S PIZZA  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH6786012    PWS NAME: ST PETER OF THE FIELDS PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6762018    STU NAME: ST PETER OF THE FIELDS


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH6788112    PWS NAME: DOLLAR GENERAL NO 6748 PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 6762166    STU NAME: DOLLAR GENERAL NO 6748


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

