

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5400112 PWS NAME: COLDWATER VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456397 STU NAME: COLDWATER VILLAGE

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>RADIOLOGICAL Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5400112 PWS NAME: COLDWATER VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: COLDWATER, VILLAGE OF DISTRIBUTION

Effective Date: 2/17/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	20 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) Quarterly
TOTAL COLIFORM (TCR) - 3100	5 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

***** TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes														
<i>Lead & Copper Sample Date(s):</i>														
<i>HAA5 & TTHM Quarterly Sample Date(s):</i>			<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>TCR Monthly Sample Date(s):</i>														
	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>		
<i>Total Chlorine Sample Date(s):</i>														

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5400212 PWS NAME: FORT RECOVERY VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456398 STU NAME: FORT RECOVERY VILLAGE

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) Quarterly
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>RADIOLOGICAL Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>Date CCR sent to Ohio EPA:</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5400212 PWS NAME: FORT RECOVERY VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: FORT RECOVERY VILLAGE DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	10 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	2 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

***** TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead & Copper Sample Date(s):</i>												
<i>HAA5 & TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5400312 PWS NAME: GRAND LAKE MHP

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456399 STU NAME: GRAND LAKE MHP

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5400312 PWS NAME: GRAND LAKE MHP

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: GRAND LAKE MHP DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
Lead & Copper Sample Date(s):												
HAA5 & TTHM Sample Date(s):												
TCR Monthly Sample Date(s):												
	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5400412 PWS NAME: LAKE SHORE RESORT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456400 STU NAME: LAKE SHORE RESORT
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5400612 PWS NAME: MENDON VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456401 STU NAME: MENDON WTP

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>RADIOLOGICAL Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5400612 PWS NAME: MENDON VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: MENDON, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>HAA5 & TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5400912 PWS NAME: NORTHMOOR LANDINGS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456404 STU NAME: NORTHMOOR LANDINGS
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5401012 PWS NAME: PARK GRAND RESORT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456405 STU NAME: PARK GRAND RESORT
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5401112 PWS NAME: ROCKFORD VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456406 STU NAME: ROCKFORD VILLAGE

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>RADIOLOGICAL Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5401112 PWS NAME: ROCKFORD VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: ROCKFORD, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	10 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	2 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

***** TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead & Copper Sample Date(s):</i>												
<i>HAA5 & TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5401212 PWS NAME: ST CHARLES SEMINARY

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456407 STU NAME: SAINT CHARLES SEMINARY

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 7/1/2009 and 9/30/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>RADIOLOGICAL Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5401312 PWS NAME: SAINT HENRY VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456408 STU NAME: SAINT HENRY WTP

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5401312 PWS NAME: SAINT HENRY VILLAGE PWS

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: ST HENRY, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	2 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>HAA5 & TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5401512 PWS NAME: SPIRITUAL CENTER OF MARIA STEIN

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5456410 STU NAME: SPIRITUAL CENTER OF MARIA STEIN


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5401612 PWS NAME: WOODHAVEN MHP PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456411 STU NAME: WOODHAVEN MHP
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5401712 PWS NAME: COTTONWOOD PARK
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456412 STU NAME: COTTONWOOD PARK INC
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5402012 PWS NAME: CLUB ISLAND ASSOCIATION

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456415 STU NAME: CLUB ISLAND ASSOCIATION STU 1

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5402012 PWS NAME: CLUB ISLAND ASSOCIATION

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: CLUB ISLAND ASSOCIATION DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
HAA5 & TTHM Sample Date(s):												
TCR Monthly Sample Date(s):												
	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5402112 PWS NAME: BAYVIEW WATER ASSOCIATION
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456416 STU NAME: BAYVIEW WATER ASSOCIATION
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5402212 PWS NAME: VILLAGE OF CHICKASAW

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456417 STU NAME: CHICKASAW WTP

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 6/1/2009 and 10/31/2009
BROMATE	BROMATE - 1011	1 Sample(s) Monthly
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes												
<i>INORGANIC Sample Date(s):</i>												
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)			Apr - Jun Sample Date(s)			Jul - Sept Sample Date(s)			Oct - Dec Sample Date(s)		
<i>NITRATE Sample Date(s):</i>												
<i>RADIOLOGICAL Sample Date(s):</i>												
<i>BROMATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5402212 PWS NAME: VILLAGE OF CHICKASAW

PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: CHICKASAW, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes											
HAA5 & TTHM Sample Date(s):											
TCR Monthly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov Dec
Total Chlorine Sample Date(s):											

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5430012 PWS NAME: AMERICAN LEGION POST 345
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456419 STU NAME: AMERICAN LEGION POST 345
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5430112 PWS NAME: AMERICAN LEGION POST 571
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456420 STU NAME: AMERICAN LEGION POST 571
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes

Nitrate Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5430612 PWS NAME: BEHMS LANDING A
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456422 STU NAME: BEHMS LANDING A
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5430912 PWS NAME: FIVE BROTHERS BAR & GRILL
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456423 STU NAME: FIVE BROTHERS BAR & GRILL
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5431112 PWS NAME: CARTER LUMBER CO CELINA
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456424 STU NAME: CARTER LUMBER CO CELINA STU 1
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5431412 PWS NAME: CHATT HOME RESTAURANT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456427 STU NAME: CHATT HOME RESTAURANT
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5431712 PWS NAME: EDEN HAVEN PARK-EAST
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456428 STU NAME: EDEN HAVEN PARK EAST
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5431812 PWS NAME: EDEN HAVEN PARK-WEST
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456429 STU NAME: EDEN HAVEN PARK WEST
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5432012 PWS NAME: MERCER CO ELKS CLUB 2170
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456430 STU NAME: ELKS CLUB NO 2170 SOUTH
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 3/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5432212 PWS NAME: SUNNY SIDE INN
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456432 STU NAME: SUNNY SIDE INN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5432412 PWS NAME: FRANKLIN ELEMENTARY SCHOOL-CELINA

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456433 STU NAME: FRANKLIN ELEMENTARY SCHOOL

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5432412 PWS NAME: FRANKLIN ELEMENTARY SCHOOL-CELINA

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: FRANKLIN ELEMENTARY SCH. DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code

Monitoring Requirements

LEAD - 1030 & COPPER - 1022

Not Required

TOTAL COLIFORM (TCR) - 3100

1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5432512 PWS NAME: FORT RECOVERY INDUSTRIES

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456434 STU NAME: FORT RECOVERY INDUSTRIES INC

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5432512 PWS NAME: FORT RECOVERY INDUSTRIES

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: FORT RECOVERY INDUSTRIES DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code

Monitoring Requirements

LEAD - 1030 & COPPER - 1022

Not Required

TOTAL COLIFORM (TCR) - 3100

1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5432812 PWS NAME: SHINGLE SHACK RESTAURANT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456435 STU NAME: SHINGLE SHACK REST STU 1
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5433112 PWS NAME: KNIGHTS OF SAINT JOHN PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456436 STU NAME: KNIGHTS OF ST. JOHN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5433212 PWS NAME: LAKE DRIVE IN
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456437 STU NAME: LAKE DRIVE IN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2009 and 9/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5433412 PWS NAME: MARION LOCAL ELEMENTARY

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456438 STU NAME: MARION LOCAL ELEMENTARY SCHOOL

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) Quarterly
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5433412 PWS NAME: MARION LOCAL ELEMENTARY

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: MARION LOCAL ELEMENTARY DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code

Monitoring Requirements

LEAD - 1030 & COPPER - 1022

10 Sample(s) between 6/1/2009 and 9/30/2009

TOTAL COLIFORM (TCR) - 3100

1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes				
<i>Lead & Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5433512 PWS NAME: MARION LOCAL HIGH SCHOOL

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456439 STU NAME: MARION LOCAL HIGH SCHOOL

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5433512 PWS NAME: MARION LOCAL HIGH SCHOOL

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: MARION LOCAL HIGH SCHOOL DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes				
<i>Lead & Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5433712 PWS NAME: BUNGE PARK

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5456441 STU NAME: BUNGE PARK


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5433812 PWS NAME: MOTOR INN AUTO TRUCK STOP PWS

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5456442 STU NAME: MOTOR INN AUTO TRUCK STOP STU 1


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	Sample should be taken at EP001
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	Sample should be taken at DS000

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5434112 PWS NAME: NORTHMOOR GOLF LLC
 PWS TYPE: Transient Noncommunity SOURCE: Ground Water
 STU ID: 5456443 STU NAME: NORTHMOOR COUNTRY CLUB
 Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5434712 PWS NAME: PIT STOP TAVERN
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456445 STU NAME: PIT STOP TAVERN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5434812 PWS NAME: PHILOTHEA COUNTRY CLUB
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456446 STU NAME: PHILOTHEA COUNTRY CLUB INC
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5435412 PWS NAME: ST. JOE STORE
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456448 STU NAME: SAINT JOE STORE
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5435612 PWS NAME: ST. PAULS UNITED CHURCH OF CHRIST
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456450 STU NAME: SAINT PAULS U CHURCH OF CHRIST
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5435912 PWS NAME: STARLIGHT DRIVE IN THEATER
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456451 STU NAME: STARLIGHT DRIVE IN THEATER
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 9/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5436412 PWS NAME: ZION LUTHERAN CHURCH - ROCKFORD

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5456452 STU NAME: ZION LUTHERAN CHURCH - ROCKFORD


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes

Nitrate Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5437112 PWS NAME: RUMORS AT THE LAKE
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456455 STU NAME: RUMORS AT THE LAKE
Effective Date: 5/19/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5437212 PWS NAME: DOSS LANDING
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456456 STU NAME: DOSS LANDING
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 11/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5437312 PWS NAME: DUCKFOOT-ARNOLD LANDING PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456457 STU NAME: DUCKFOOT-ARNOLD LANDING
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5437412 PWS NAME: HECHTS LANDING - WELL #1
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456458 STU NAME: HECHTS LNDNG BTHHS WELL
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 11/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5437512 PWS NAME: HECHTS LANDING 2 WELL PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456459 STU NAME: HECHTS LANDING LGTPL WELL
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5437812 PWS NAME: HEMMELGARN & SONS, INC. PWS

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456460 STU NAME: HEMMELGARN AND SONS INC

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5437812 PWS NAME: HEMMELGARN & SONS, INC. PWS

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: HEMMELGARN AND SONS, INC DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code

Monitoring Requirements

LEAD - 1030 & COPPER - 1022

Not Required

TOTAL COLIFORM (TCR) - 3100

1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438012 PWS NAME: KORNER KAFE - MARIA STEIN
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456461 STU NAME: KORNER KAFE - MARIA STEIN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5438212 PWS NAME: PAX MACHINE WORKS, INC.

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456462 STU NAME: PAX MACHINE WORKS INC

Effective Date:9/18/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
ARSENIC	ARSENIC - 1005	1 Sample(s) Quarterly
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
<i>INORGANIC Sample Date(s):</i>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5438212 PWS NAME: PAX MACHINE WORKS, INC.

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: PAX MACHINE WORKS, INC. DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
--------------------------------------	---------------------------------	---------------------------------	----------------------------------	---------------------------------

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438412 PWS NAME: TSC STORE 240 PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456463 STU NAME: TSC STORE
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438512 PWS NAME: VFW POST 5135
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456464 STU NAME: VFW POST 5135
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438612 PWS NAME: WAGON WHEEL NITE CLUB
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456465 STU NAME: WAGON WHEEL NITE CLUB
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes

Nitrate Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438712 PWS NAME: WENDELIN TAVERN
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456466 STU NAME: WENDELIN TAVERN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5438912 PWS NAME: BAYVIEW SUN & SNOW
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456467 STU NAME: BAYVIEW LODGE INC
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 11/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439012 PWS NAME: WINDY CORNERS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456468 STU NAME: WINDY CORNERS
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439212 PWS NAME: ITS IT LANDING PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456469 STU NAME: ITS IT LANDING
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439312 PWS NAME: LEES LANDING PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456470 STU NAME: LEES LANDING
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439412 PWS NAME: LEFELD IMPLEMENT, INC.
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456471 STU NAME: LEFELD IMPLEMENT INC
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439612 PWS NAME: MARIA STEIN FAMILY PRACTICE
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456472 STU NAME: MARIA STEIN FAMILY PRACTICE
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439712 PWS NAME: D & W MARINA
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456473 STU NAME: D & W MARINA
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5439812 PWS NAME: KOZY KAMP GROUND - BATH HOUSE WELL

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5456474 STU NAME: KOZY KAMP GROUND - BATH HOUSE WELL


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 9/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes

Nitrate Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5439912 PWS NAME: MONTEZUMA BAY RESORT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456475 STU NAME: MONTEZUMA BAY RESORT
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 9/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5440112 PWS NAME: ODOT MERCER CO GARAGE

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456477 STU NAME: ODOT MERCER CO GARAGE

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5440112 PWS NAME: ODOT MERCER CO GARAGE

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: ODOT-MERCER CO GARAGE DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2009 and 9/30/2009
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

<i>Lead & Copper Sample Date(s):</i>
--

<i>TCR Quarterly Sample Date(s):</i>

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5440312 PWS NAME: S AND K PRODUCTS COMPANY

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001

STU ID: 5456479 STU NAME: S & K PRODUCTS CO

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRITE	NITRITE - 1041	Not Required
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5440312 PWS NAME: S AND K PRODUCTS COMPANY

PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000

FACILITY NAME: S&K PRODUCTS COMPANY DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.

If you receive a Total Coliform Positive result, contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

Use for Sample Tracking Purposes

<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
--------------------------------------	---------------------------------	---------------------------------	----------------------------------	---------------------------------

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440412 PWS NAME: BEHMS LANDING RESTAURANT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456480 STU NAME: BEHMS LANDING RESTAURANT STU 1
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	Sample should be taken at EP001
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	Sample should be taken at DS000

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440412 PWS NAME: BEHMS LANDING RESTAURANT
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460520 STU NAME: BEHMS LANDING RESTAURANT STU 2
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	Sample should be taken at EP002
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	Sample should be taken at DS000

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440512 PWS NAME: ODNR-GRAND LAKE ST. MARYS STATE PARK-WIN
 PWS TYPE: Transient Noncommunity SOURCE: Ground Water
 STU ID: 5460724 STU NAME: ODNR WINDY POINT
 Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440612 PWS NAME: MARIA STEIN CENTER
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5456481 STU NAME: MARIA STEIN CENTER
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440812 PWS NAME: KOZY KAMP GROUND
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460688 STU NAME: KOZY KAMP GROUND
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 9/30/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5440912 PWS NAME: DEERFIELD GOLF COURSE
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460675 STU NAME: DEERFIELD GOLF COURSE
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441012 PWS NAME: BEHMS LANDING B
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460723 STU NAME: BEHMS LANDING B
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441112 PWS NAME: NIEKAMP FARM & FLEA MARKET
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460739 STU NAME: NIEKAMP FARM & FLEA MARKET
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441212 PWS NAME: BUCKS INN PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460819 STU NAME: BUCKS INN
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441312 PWS NAME: VFW POST 6515 PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5460851 STU NAME: VFW POST 6515
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441412 PWS NAME: HECHTS LANDING MHP
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5461007 STU NAME: HECHTS LANDING MHP
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5441512 PWS NAME: ZUMA THRU/SUNSET LAUNDRY/CAR WASH

PWS TYPE: Transient Noncommunity SOURCE: Ground Water

STU ID: 5461589 STU NAME: ZUMA THRU/SUNSET LAUNDRY/CAR WASH


Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2009 and 12/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes

Nitrate Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

2009 CONTAMINANT MONITORING SCHEDULE


PWS ID: OH5441712 PWS NAME: HECHTS LANDING CAMPGROUND PWS
PWS TYPE: Transient Noncommunity SOURCE: Ground Water
STU ID: 5461919 STU NAME: HECHTS LANDING CAMPGROUND
Effective Date: 1/1/09

THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE - 1040	1 Sample(s) between 6/1/2009 and 10/31/2009	<i>Sample should be taken at EP001</i>
NITRITE - 1041	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2009 and 10/31/2009	<i>Sample should be taken at DS000</i>

Where to Collect Samples For a Small Public Water System



* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

2009 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH5400011 PWS NAME: CELINA CITY

PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: EP001

STU ID: 5456396 STU NAME: CELINA CITY

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
INORGANICS	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2009 and 10/31/2009
NITRATE	NITRATE - 1040	1 Sample(s) Monthly
NITRITE	NITRITE - 1041	Not Required
RADIOLOGICALS	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
BROMATE	BROMATE - 1011	1 Sample(s) Monthly
TOTAL ORGANIC CARBON (TOC)		1 Paired Sample Set Monthly *
VOLATILE ORGANIC CHEMICALS (VOC)		1 Sample(s) between 6/1/2009 and 10/31/2009
SYNTHETIC ORGANIC CHEMICALS (SOC)	See SOC Group 1 List Below	1 Sample(s) between 4/1/2009 and 4/30/2009 1 Sample(s) between 5/1/2009 and 5/31/2009 1 Sample(s) between 6/1/2009 and 6/30/2009

REMINDER: Consumer Confidence Report (CCR) is due July 1, 2009

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: * A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>BROMATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												

2009 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH5400011 PWS NAME: CELINA CITY

PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: DS000

FACILITY NAME: CELINA CITY DISTRIBUTION

Effective Date: 1/1/09

THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 4 Sample(s) Quarterly
TOTAL COLIFORM (TCR) - 3100	10 Sample(s) Monthly between 1/1/2009 and 12/31/2009
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

** Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northwest District Office - DDAGW representative immediately at 419-352-8461.

*** TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
	1st Half Sample Date(s)						2nd Half Sample Date(s)					
Lead & Copper Initial Monitoring Sample Date(s):												
HAA5 & TTHM Quarterly Sample Date(s):	Jan - Mar Sample Date(s)			Apr - Jun Sample Date(s)			Jul - Sept Sample Date(s)		Oct - Dec Sample Date(s)			
TCR Monthly Sample Date(s):	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												