

**2011 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5800212    PWS NAME: RIVERS EDGE OF MALTA  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
Groundwater Rule Minimal Treatment System

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856721    FACILITY NAME: RIVERS EDGE OF MALTA**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2011 and 10/31/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5800412 PWS NAME: MALTA VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856722 FACILITY NAME: MALTA WTP**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2011 and 10/31/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	2,3,7,8-TCDD - 2063	Not Required

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856722. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2011**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>





**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5800712 PWS NAME: WOODLAND HILLS ESTATES**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856724 FACILITY NAME: WOODLAND HILLS ESTATES**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856724. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2011**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5800912      PWS NAME: STOCKPORT VILLAGE PWS**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856725      FACILITY NAME: STOCKPORT VILLAGE**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2011 and 9/30/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856725. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2011**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5801003      PWS NAME: MORGAN MEIGSVILLE RURAL**  
**PWS TYPE: Community    SOURCE: Purchased Ground Water    Sample Monitoring Point: DS000**  
**FACILITY NAME: MORGAN MEIGSVILLE RURAL DISTRIBUTION**  
*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2011 and 9/30/2011
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2011 and 12/31/2011
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5801103 PWS NAME: WEST MALTA RURAL WATER PWS**  
**PWS TYPE: Community SOURCE: Purchased Ground Water Sample Monitoring Point: DS000**  
**FACILITY NAME: WEST MALTA RURAL WATER DISTRIBUTION**

**Effective Date: 7/18/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	20 Sample(s) between 7/1/2011 and 12/31/2011
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2011 and 12/31/2011
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

***Lead Consumer Notice needs issued to sampling participants within thirty days of receipt of results and verification submitted to Ohio EPA within ninety days from the end of the monitoring period.***

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>
<i>Total Chlorine Sample Date(s):</i>



**2011 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5830312    PWS NAME: MOOSE LODGE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
Groundwater Rule Minimal Treatment System

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856728    FACILITY NAME: MOOSE LODGE**

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2011 and 12/31/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5831112 PWS NAME: MIBA BEARINGS US LLC**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856730 FACILITY NAME: MIBA BEARINGS US LLC**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2011 and 10/31/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856730. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
NITRATE Sample Date(s):
VOC Sample Date(s):
SOC Group 1 Sample Date(s):

**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5831112 PWS NAME: MIBA BEARINGS US LLC**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: MIBA BEARINGS US LLC DISTRIBUTION**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2011 and 12/31/2011

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

<b>Use for Sample Tracking Purposes</b>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5831212    PWS NAME: OHIO POWER/HOOK LAKE-A1**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856731    FACILITY NAME: OHIO POWER HOOK LAKE A1**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5831312 PWS NAME: OHIO POWER/HOOK LAKE-A3**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856732 FACILITY NAME: OHIO POWER HOOK LAKE A3**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1 FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5831712    PWS NAME: OHIO POWER/MAPLE GROVE-G**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856735    FACILITY NAME: OHIO POWER MAPLE GROVE G**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5832912    PWS NAME: OHIO POWER/SAND HOLLOW-C1**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856740    FACILITY NAME: OHIO POWER SAND HOLLOW C1**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5833112    PWS NAME: OHIO POWER/SAND HOLLOW-C3**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856742    FACILITY NAME: OHIO POWER SAND HOLLOW C3**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5833312 PWS NAME: OHIO POWER/SAWMILL-D1**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856743 FACILITY NAME: OHIO POWER SAWMILL D1**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1 FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5833812    PWS NAME: OHIO POWER/WINDY HILL-E**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856747    FACILITY NAME: OHIO POWER WINDY HILL E**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5833912    PWS NAME: OHIO POWER/WOOD GROVE-H**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856748    FACILITY NAME: OHIO POWER WOOD GROVE H**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5834622      PWS NAME: AEP-MUSKINGUM RIVER U1-4**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856750      FACILITY NAME: AEP MUSKINGUM RIVER UNITS 1-4**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 10/1/2011 and 12/31/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856750. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
NITRATE Sample Date(s):
VOC Sample Date(s):
SOC Group 1 Sample Date(s):

**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5834622      PWS NAME: AEP-MUSKINGUM RIVER U1-4

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

**FACILITY NAME: AEP-MUSKINGUM RIVER U1-4 DISTRIBUTION**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required, Unless State Delinquency Notice Received
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2011 and 12/31/2011
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
TCR Quarterly Sample Date(s):	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5836112    PWS NAME: OHIO POWER/HOOK LAKE-A4**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5856755    FACILITY NAME: OHIO POWER HOOK LAKE A4**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5836412    PWS NAME: OHIO POWER/BICENT-K1**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 6156756    FACILITY NAME: OHIO POWER BICENTENNIAL K1**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5836512    PWS NAME: OHIO POWER/BICENT-K2  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
Groundwater Rule Minimal Treatment System

**Effective Date: 7/18/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 6156757    FACILITY NAME: OHIO POWER BICENTENNIAL K2**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

<i>Chemicals</i>	<i>Monitoring Requirements</i>	<i>Sample Monitoring Point</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/30/2011 and 9/30/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>
Nitrate Sample Date(s):

**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5836612      PWS NAME: MAHLE ENGINE COMPONENTS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5860713      FACILITY NAME: MAHLE ENGINE COMPONENTS**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 3 List Below	Not Required

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5860713. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 3 Chemicals: BHC-GAMMA (LINDANE) - 2010, METHOXYCHLOR - 2015, DIQUAT - 2032, GLYPHOSATE - 2034, POLYCHLORINATED BIPHENYLS (PCB) - 2383

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5836612 PWS NAME: MAHLE ENGINE COMPONENTS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: MAHLE ENG COMP DISTRIBUTION**

*Groundwater Rule Minimal Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2011 and 12/31/2011

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

<b>Use for Sample Tracking Purposes</b>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2011 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5836712    PWS NAME: MORGAN HARDWARE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
Groundwater Rule Substantial Treatment System

**Effective Date: 1/1/11**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378


**STATE FACILITY ID: 5861411    FACILITY NAME: MORGAN HARDWARE TREATMENT PLANT**

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE - 1040</b>	1 Sample(s) between 6/1/2011 and 10/31/2011	<b>Sample should be taken at EP001</b>
<b>NITRITE - 1041</b>	Not Required	

**STATE FACILITY ID: DS1    FACILITY NAME: DISTRIBUTION SYSTEM**

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2011 and 12/31/2011	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2011 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5800112 PWS NAME: CHESTERHILL VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STATE FACILITY ID: 5856720 FACILITY NAME: CHESTERHILL VILLAGE**

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE - 1040	1 Sample(s) between 6/1/2011 and 10/31/2011
<b>NITRITE</b>	NITRITE - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2011 and 10/31/2011

**Unless Otherwise Noted, the Sample Monitoring Point for All Chemicals Listed Above is EP001 and the State Facility ID is 5856720. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2011**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2011 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5800112      PWS NAME: CHESTERHILL VILLAGE PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: CHESTERHILL, VILLAGE OF DISTRIBUTION

*Groundwater Rule Substantial Treatment System*

**Effective Date: 1/1/11**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2011 and 9/30/2011
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required, Unless State Delinquency Notice Received
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2011 and 12/31/2011
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**For All Chemicals and Total Coliform Requirements Listed Above, the State Facility ID is DS1. The Sample Monitoring Point Codes for TTHM and HAA5 Samples are MR000/RD000, and DS000 for Asbestos Samples. This Information Must Be Provided to the Laboratory for Results to be Submitted to Ohio EPA.**

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southeast District Office - DDAGW representative immediately at 740-385-8501.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												